

TECHNICAL SUPPORT MATERIAL

Routine and Preventative Maintenance

Hood Fan Kit (388-1007) is Signal Only

ADS does not allow electrical power from the dishwasher control to box be used for power to any other motor such as a hood exhaust fans.


The kit only provides slave points and a time extending relay. The conduit and wire needed to reach the enclosure for the fan will be supplied by others. The power control box (enclosure), contactor, wire, conduit and motors are supplied by others. ADS cannot supply these items because they are different for each installation.



Power for the fan motor must come from the building's service drop or circuit panel box. A designated circuit breaker for the motor will be installed in this box and labeled.




Conduit from the breaker box may already exist and will lead to an enclosure box near the dishwasher for the hood motor control. If this is not the case, it will need to be provided. From the ADS Hood Fan Kit, install this relay next to the fan motor contactor. Wire according to wire diagram supplied in kit.



Next, inside the dishmachine's control box, insert the slave points (291-3028) on the conveyor motor contactor for conveyor machines and the wash contactor for the HT-25. Wire according to wire diagram supplied in kit.

The fan motor installed above a hood is powered by the motor contactor and controlled by the dishwasher signal. The ADS hood fan kit will allow a "time-on setting" after the dishwasher has turned off.

10/28/2014



DISHMACHINE