


P/N 091-3007 has been superseded in the ET applications by 088-1072



**INSTALLATION INSTRUCTIONS: TO BE PERFORMED BY A QUALIFIED SERVICE TECHNICIAN**

- #1 Shut-off power to the machine at main breaker panel. Then remove control box cover.
- #2 Remove wires from existing mercury relay, and remove relay from the control box.
- #3 Install new contactor kit using the plate, studs, and nuts provided in existing holes.
- #4 Connect the black wire #1 on the mercury relay to position #1 on the new contactor.
- #5 Connect the red wires #2 on the mercury relay to position #2 on the new contactor.
- #6 Connect the brown wire #3 on the mercury relay to position #3 on the new contactor.
- #7 Connect the white wires and the one black wire coming from the electric counter on #4 on the mercury relay to position #4 on the new contactor.
- #8 Verify that all connections on the new contactor are secure and tight.
- #9 Replace control box cover and turn the main power supply on and check the machine for proper function.
- #10 To dispose of the mercury relay, package the relay for shipment and contact American Dish Service for a return shipment call tag (800)-922-2178.

**NOTE:** This kit contains a connector kit P/N: 088-1074 to assist in the conversion process. The screws for terminals #'s 3 and 4 on the new contactor are supplied in this connector kit.