



P/N 091-3007 has been superseded in the 3D, 3DS, & LW application by 088-1073



INSTALLATION INSTRUCTIONS: TO BE PERFORMED BY A QUALIFIED SERVICE TECHNICIAN

#1 Shut-off power to the machine at main breaker panel. Then remove control box cover.

#2 Remove wires from existing mercury relay, and remove relay from the control box.

#3 Install new contactor and plate using existing bolts and nuts.

NOTE: This kit also contains a wire extension kit #088-1075 to assist in the conversion process.

#4 Connect the black wire #1 on the mercury relay to position #1(T1) on the new contactor.

#5 Connect the red wires #2 on the mercury relay to position #2(L1) on the new contactor.

#6 Connect the brown wire #3 on the mercury relay to position #3 on the new contactor.

#7 Connect the white wires and the one black wire coming from the electric counter on #4 on the mercury relay to position #4 on the new contactor.

#8 Verify that all connections on the new contactor are secure and tight.

#9 Replace control box cover and turn the main power supply on and check the machine for proper function.

#10 To dispose of the mercury relay, package the relay for shipment and contact American Dish Service for a return shipment call tag (800)-922-2178.

NOTE: This kit contains a connector kit P/N: 088-1074 to assist in the conversion process.

The screws for terminals #'s 3 and 4 on the new contactor are supplied in this connector kit.